

Reservdelislista/Spare part list/Ersatzteilliste

Truckladdare/Battery charger/Ladegerät Typ/Type/Typ:

STC 48/100

In/Input/Eingang:

3x220-230/380-400V 60Hz

Ut/Output/Ausgang:

48V DC 100A

Recommended Primary Cable:


Secondary cable:

Primärström/Primary current (A/Phase):

Elschema/Circuit diagram/Schaltplan #:

Kapsling/Cabinet/Gehäuse:

W4



Pos	Benämning/Name/Benennung	Ref	Data
1	Säkring/Fuse/Sicherung	F	
2	Säkring/Fuse/Sicherung	F	
3	Kontaktor/Contactor/Kontaktor	K1	
4	Kontaktor/Contactor/Kontaktor	K2	
5	Strömbrytare/Switch/Stromschalter	S1	
6	Fläkt/Fan/Ventilator	E	pcs out + pcs heat sink
7	Diod/Diode/Diode pos	D	
8	Diod/Diode/Diode neg	D	
9	Motstånd/Resistor/Widerstand	R	
10	Varistor/Varistor/Varistor	Va1	
11	Transformator/Transformer/Transformator	T	0 pcs
12	Drossel/Choke/Drossel	L	0 pcs
13	Manöver trafo/Aux.transf/	T	pcs
14	Styrkort/Main pcb/Haupt l.b	U1	